

Hospital CT Procedures
(Biopsy, Cryoablation, Aspiration, etc)
10/12/2021

Setup:

- PA and Lateral Scout from above area of interest to below area of interest.

DFOV:

- Appropriate for patients body habitus. Use same DFOV as prior exam when available.

Scan Parameters:

- Technologist to scan appropriate area according to Radiologist preference/need

Technique:

- Scanner to be set on automatic exposure control (AEC). If AEC isn't available, the Technologist and/or Radiologist will adjust the mA and/or kVp according to patient size.
- Protocol designed to minimize the amount of radiation while maximizing the yield and produce diagnostically acceptable image quality.